
NOTES

- 1. CUT TUBING TO FIT AS REQUIRED.
- CONNECT WHITE "POLYPROPYLENE" TUBING ON PRESSURE SIDE (INLET) OF VALVE.
- CONNECT CLEAR "POLYETHYLENE" TUBING ON FREE FLOW SIDE (VALVE TO BUBBLER HEAD) ONLY
- REFER TO 58874/VRK5874 OPERATION AND MAINTENANCE MANUAL FOR INSTALLATION INSTRUCTIONS.
- [5] MUST APPLY 1 DOT OF LOCTITE 222MS THREAD-LOCKER ON FEMALE THREADS OF PUSH BUTTON. SEE 5874 OPERATION AND MAINTENANCE MANUAL (PAGE 5 OF 5) FOR PROPER APPLICATION PROCEDURE.

PARTS BREAKDOWN

Haws 1435



www.DrinkingFountainDoctor.com 1-800-518-5388