

PARTS LIST

1. 2.	0393009 0393008 0393029 3323182		11/2" x 211/2" CP Vacuum Breaker 11/2" x 131/2" CP Vacuum Breaker (ADA height) 11/2" x 211/2" CP Vacuum Breaker w/2" Offset Vacuum Breaker Repair Kit
2. 3.	0306093	V-057-A F-2-A	11/2" Slip Joint Coupling
4.	0309001	DV-1	Diverter Valve Body
 5.		DV-1001-A	Wall Support Kit
6.	0309027		Outlet Tube Gasket
7A.	0309029		Outlet Tube
7B.	0396525		Outlet Tube w/11/2" Offset
8.	0306045	F-2	11/2" Coupling Nut
9.	0306146	F-5-A	1 ¹ /2" Spud Coupling Assembly
10.	3309044	DV-32-AA	Spray Arm Replacement Kit
	3309016	DV-1013-A	Bio-Gard Spray Arm Replacement Kit
	3309077	DV-1014-A	Short Spray Arm Replacement Kit
			(for use w/F-182 Offset Outlet Tube)
11.	3309032	DV-1007-A	Spray Arm Repair Kit
12.	3309037	DV-1003-A	Pivot Replacement Kit
13.	3309036	DV-1002-A	Deoseptic Pivot Replacement Kit
14.	0309024	DV-21	Plug Button
15.	0309033	DV-33-A	Swivel & Ball Check Assembly
16.	0309036	DV-36-A	Aspirator Tube Assembly
17.	0309018	DV-29	Deoseptic Solution Bottle

BEDPAN WASHER REBUILD KITS			
CODE NO.	KIT NO.	DESCRIPTION	
		DIVERTER REBUILD KIT	
5309031	DV-50-A	Includes Outlet Tube Gasket (item 6), Spray	
		Arm Repair Kit (item 11), and all items in Pivot	
		Replacement Kit (item 12) except Pivot.	
		DEOSEPTIC DIVERTER REBUILD KIT	
3309040	DV-1004-A	Includes Outlet Tube Gasket (item 6), Spray	
		Arm Repair Kit (item 11), and all items in Pivot	
		Replacement Kit (item 13) except Pivot.	
To convert a	Standard Dive	erter Assembly to a Deoseptic Diverter Assembly use:	
3309048	DV-1005-A	DEOSEPTIC CONVERSION KIT	

The information contained in this document is subject to change without notice.

SLOAN VALVE COMPANY • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131

Phone: 1-800-9-VALVE-9 or 1-847-671-4300 • Fax: 1-800-447-8329 or 1-847-671-4380 • http://www.sloanvalve.com

Made in the U.S.A.

BPW M.G. - Rev. 0a (05/03)


Troubleshooting and Maintaining the Sloan Slimline[®] Bedpan Washer

See Royal Flushometer Troubleshooting and Maintenance Guide for all problems regarding the flushometer valve and the flushing discharge.

1. PROBLEM: Diverter leaking at Spray Arm.

CAUSE: (a.) Diverter Spray Arm (old style) is damaged. (b.) Spray Arm O-Ring is damaged or installed improperly.

- SOLUTION: (a.) Replace Diverter Arm with new Spray Arm Replacement Kit.
 NOTE: On old style diverter Spray Arm, the Spray Arm O-Ring was placed on groove at the end of the Spray Arm. When installing new Spray Arm Kit, place Washer into bottom of hole of Nozzle Pivot. Then place the O-Ring on top of Washer. Insert new Spray Arm into the Pivot, pressing in slightly. While holding Spray Arm in place, tighten Set Screw.
 - (b.) Re-install O-Ring as described above in step (a.). If leakage persists replace using Spray Arm Kit DV-1007-A.



2. PROBLEM: Diverter leaking at Nozzle Pivot.

CAUSE: (a.) One or both Pivot O-Rings are worn. (b.) Diverter Seal Washer worn or missing. (c.) Nozzle Pivot damaged or defective.

- **SOLUTION:** (a.) Replace Nozzle Pivot Assembly. Use *Pivot Replacement Kit.*
 - (b.) Replace Pivot Seals. Use Diverter Rebuild Kit.
 - (c.) Replace Nozzle Pivot Assembly. Use *Pivot Replacement Kit.*
- 3. PROBLEM: Erratic spray pattern from Spray Arm Nozzle.

CAUSE: (a.) Debris clogging Nozzle Screen. (b.) Damaged or missing Nozzle Screen or Spray Disc.

- **SOLUTION:** (a.) Wash Nozzle Screen under running water. (b.) Replace using DV-1007-A Spray Arm Replacement Kit.
- 4. PROBLEM: Deoseptic Solution not siphoning from Bottle during flush cycle (Deoseptic models only).

CAUSE: (a.) Adjusting Screw not open.

- (b.) Aspirator Tube Screen clogged.
- (c.) Aspirator Tube not installed completely onto Swivel & Ball Check Assembly.
- (d.) Aspirator Tube cracked.
- (e.) Rubber Ball Check stuck inside Swivel & Ball Check Assembly.

- **SOLUTION:** (a.) Open Adjusting Screw until adequate amount of solution is siphoned from Bottle during flush cycle.
 - (b.) Remove Solution Bottle. Remove Aspirator Tube from Swivel & Ball Check Assembly and wash Screen under running water.
 - (c.) Remove Solution Bottle. Make sure Aspirator Tube is pushed completely onto nipple of Swivel and Ball Check Assembly.
 - (d.) Replace Aspirator Tube Assembly.
 - (e.) Remove Solution Bottle and Aspirator Tube from Swivel & Ball Check Assembly. Gently insert small implement (paper clip, small dia. hex key, etc.) into nipple of Swivel & Ball Check Assembly to dislodge Rubber Ball Check. Stop pushing once water starts to trickle from nipple.

NOTE: If Ball is pushed too hard or too far it may fall out of seat. Should this occur, the Swivel & Ball Check Assembly must be removed and Ball replaced. To do this, remove Retaining Ring using retaining clip pliers. Pull Swivel & Ball Check Assembly off of Adjusting Screw being careful not to drop Rubber Ball Check. Place Rubber Ball back into seat of Swivel & Ball Check Assembly and reassemble. If Ball and Seals appear worn rebuild.

5. PROBLEM: Water leaking back into Solution Bottle.

- CAUSE: (a.) Rubber Ball damaged or missing. (b.) Rubber Ball not sitting in seat of Swivel & Ball Check Assembly.
- **SOLUTION:** (a.) Replace Rubber Ball using DV-1004-A *Deoseptic* Diverter Rebuild Kit
 - (b.) Remove Swivel & Ball Check Assembly taking care not to lose Rubber Ball. Insert Rubber Ball back into seat of Swivel & Ball Check Assembly and reassemble. NOTE: Follow steps in Solution (e.) of Problem 4.

REBUILDING THE SLOAN SLIMLINE DIVERTER ASSEMBLY:

To disassemble Diverter Valve:

Loosen Set Screw and remove Spray Arm from Pivot. Slide Pivot out of Diverter Valve Body.

To further disassemble Deoseptic Diverters:

Remove Plug Cap and Retaining Ring. Slide Swivel and Ball Check Assembly off Pivot shaft, exposing all internal components. NOTE: This disassembly can be done without removing Pivot Assembly from Diverter Valve Body.

CARE AND CLEANING INSTRUCTIONS

<u>DO NOT</u> use abrasive or chemical cleaners to clean Flushometers as they may dull the luster and attack the chrome or special decorative finishes. Use <u>ONLY</u> soap and water, then wipe dry with clean cloth or towel. While cleaning the bathroom tile, the Flushometer should be protected from any splattering of cleaner. Acids and cleaning fluids can discolor or remove chrome plating.

If further assistance is required, please contact Sloan Valve Company Installation Engineering Dept. at 1-888-SLOAN-14.

The information contained in this document is subject to change without notice.

SLOAN VALVE COMPANY • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131

Phone: 1-800-9-VALVE-9 or 1-847-671-4300 • Fax: 1-800-447-8329 or 1-847-671-4380 • http://www.sloanvalve.com

Made in the U.S.A.